

Important user information

RodStation rods and equipment are specifically intended to be used by professional chimney sweeps that are trained and competent to carry out sweeping and the use of this equipment.

1. All Health and Safety legislation must be complied with whilst using the equipment in addition to the following.
2. Wear at all times suitable Personal Protection Equipment necessary for the job.
3. When connecting rods and adaptor always make sure the connection is secure, such as a firm fit when using the threaded connectors. When using the system ensure the buttons are fully engaged and secure.
4. When using the Power sweeping
 - A. Ensure the rods and all the joints are secure and in good condition, and the appropriate sweeping brush/head is used to suit the flue size and material.
 - B. Use the required connector to secure the rods to a suitable drill. It is recommended that a suitable 18V cordless drill is used which features a safety clutch and a good choice of gearing. Mains powered drills should not be used.
 - C. Never hold the rods whilst they rotate as this can cause risk of injury. Also ensure that there is no loose clothing or material that can be snagged and pulled in whilst the rods rotate. If any snag occurs stop the drill immediately and then untangle the snag carefully.
 - D. Care must be taken to avoid excessive bending of the rods, particularly when power sweeping as this can damage the rods due to excessive overheating and stress. It is best to keep the rods as straight as possible which assists controlled sweeping.
 - E. Always keep the rotating rods and head moving up or down in the chimney to avoid excessive overheating or damage to the equipment and or flue.
5. Always clean and check the equipment after use to ensure it is in good working order and there are no corrosive deposits or moisture that can damage the equipment during storage.

Replacing nylon line on the FlueBoss head



Use a 8mm Allen key to slacken the grub screw on the inside of the adapter (do not fully remove grub screw). Remove the worn Nylon from the adapter and dispose of accordingly.




Take care to note the flue size that you will be sweeping before cutting 4 x lengths of replacement nylon to desired size.



Make sure that the holes in the adapter are clear by adjusting the grub screw. Push the nylon through the holes and align centrally.



Position the nylon in your desired configuration. Clamp the nylon securely in place by tightening the grub screw.



The final result should look like this.



Warranties

There is full 12 month replacement warranty on all RodStation rods, adaptors and the FlueBoss. This warranty does not cover items that have clearly been misused and consumable items that can wear during use including the Nylon line, brushes, wire chains and scrapers. During use rods will naturally bend and flex so may not remain perfectly straight. This is normal wear and not covered, but the fixings are.

In the unlikely event that a warranty claim is necessary, please contact RodStation and return the item to RodStation for checking. If the item is faulty a free replacement will be sent. This warranty does not affect your statutory rights.